

# Air Intake Mass Air Flow Sensor

Location of air intake mass air flow sensor and air intake filter housing.

Electrical connector.



flow sensor.