Equipment Identification System October 2014

AA-BBB-WXYZ

Unit designator:

AA-BBB

Where:

AA = State

BBB = 3 alpha forest designator

Equipment designator:

WXYZ

Where:

W = equipment category

X =equipment type (Type 3, etc.)

Y = district

Z = equipment number

Example:

AZ-CNF-E312

State: Arizona (R-3)

Forest: Coronado National Forest

Equipment category: Engine
Equipment type: Type 3
District: District 1

Equipment number: Engine number 2

Equipment Category	Designator
Engine	E
Water Tender	WT
Crew Carrier	С
Prevention (Dry)	Р
Prevention /Patrol (Wet)	PT
Battalion Chief (ADFMO)	ВС
Division Chief (DFMO)	DV
Chief (FFMO/FAFMO)	CH
Operational Support	UT
Vehicle (Utility)	
Dozer	D
Dozer Support (Tender)	DT

In the case of reserve equipment:

AA-BBB-WXYZR

Unit designator:

AA-BBB

Where:

AA = State

BBB = 3 alpha forest designator

Equipment designator:

WXYZR

Where:

W = equipment category (E = Engine, P = Prevention, D = Dozer, etc.)

X =equipment type (Type 3, etc.)

Y = district

Z = equipment number

R = reserve

Example:

AZ-CNF-E312R

State: Arizona (R-3)

Forest: Coronado National Forest

Equipment category: Engine
Equipment type: Type 3
District: District 1

Equipment number: Engine number 2

Reserve id: R